


INSTALLATION INSTRUCTIONS

DDU-0000





INSTALL INSTRUCTION

REVISION DATE


I-1 06/08/2018

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF EZSTAK LLC ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF EZSTAK LLC IS PROHIBITED.

SHEET 1 OF 4

DODGE DURANGO INSTALLATION BASE INSTALL INSTRUCTIONS





INSTALL INSTRUCTION REV

REVISION DATE

I-1 06/08/2018


PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF EZSTAK LLC ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF EZSTAK LLC IS PROHIBITED.

SHEET 2 OF 4



STEP 1: REMOVE FACTORY LOAD FLOOR AND REAR SILL



STEP 2: REMOVE PLASTIC PANELS FROM AREA



INSTALL INSTRUCTION REVISION

DATE 06/08/2018

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF EZSTAK LLC ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF EZSTAK LLC IS PROHIBITED.

SHEET 3 OF 4





FROM REAR 18mm





STEP 3: REMOVE 3RD ROW SEAT IF EQUIPED

FROM FRONT 18mm INSTALL INSTRUCTION REVISION

REVISION DATE


I-1 06/08/2018


PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF EZSTAK LLC ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF EZSTAK LLC IS PROHIBITED.

SHEET 4 OF 4

10mm NUT





STEP 4: INSTALL BASE AND REAR SILL



18mm NUT